




Types of Erosion

The break down and transport of rocks – smooth, round and sorted.	
Attrition	Rocks that bash together to become smooth/smaller.
Solution	A chemical reaction that dissolves rocks.
Abrasion	Rocks hurled at the base of a cliff to break pieces apart or scraped against the banks and bed of a river.
Hydraulic Action	Water enters cracks in the cliff, or river bank, air compresses, causing the crack to expand.

Types of Transportation

A natural process by which eroded material is carried/transported.	
Solution	Minerals dissolve in water and are carried along.
Suspension	Sediment is carried along in the flow of the water.
Saltation	Pebbles that bounce along the sea/river bed.
Traction	Boulders that roll along a river/sea bed by the force of the flowing water.

Mass Movement

A large movement of soil and rock debris that moves down slopes in response to the pull of gravity in a vertical direction.

Rock slides occur when there is a failure along the bedding plane.

ng occurs when there is inward rotation of sections of cliff. Often occur after heavy rain.

Formation of Coastal Spits - Deposition

Example: Spurn Head, Holderness Coast.

Material moved along beach in zig-zag way

Coastline changes direction

Material deposited in shallow, calm water, to form a spit

Spit

Prevailing winds bring waves in at an angle

Types of Weathering

Weathering is the breakdown of rocks where they are.	
Biological	Breakdown of rock by plants and animals e.g. roots pushing rocks apart.
Mechanical	Breakdown of rock without changing its chemical composition e.g. freeze thaw

What is Deposition?

When the sea or river loses energy, it drops the sand, rock particles and pebbles it has been carrying. This is called deposition. Heaviest material is deposited first.

Formation of Bays and Headlands

Rock fall

Debris from previous rock falls

Rockfall is the rapid free fall of rock from a steep cliff face because of gravity.

- Swash moves up the beach at the angle of the prevailing wind.
- Backwash moves down the beach at 90° to coastline, due to gravity.
- Zigzag movement (Longshore Drift) transports material along beach.
- Deposition causes beach to extend, until reaching a river estuary.
- Change in prevailing wind direction forms a hook.
- Sheltered area behind spit encourages deposition, salt marsh forms.

Unit 1c Physical Landscapes in the UK


AQA

How do waves form?

Waves are created by wind blowing over the surface of the sea. As the wind blows over the sea, friction is created - producing a swell in the water.

Why do waves break?

- Waves start out at sea.
- As waves approaches the shore, friction slows the base.
- This causes the orbit to become elliptical.
- Until the top of the wave breaks over.



Mechanical Weathering Example: Freeze-thaw weathering

Stage One

Water seeps into cracks and fractures in the rock.

Stage Two

When the water freezes, it expands about 9%. This wedges apart the rock.

Stage Three

With repeated freeze-thaw cycles, the rock breaks off.

Size of waves

Types of Waves

Constructive Waves

This wave has a **swash** that is stronger than the backwash. This therefore builds up the coast.

Destructive Waves

This wave has a **backwash** that is stronger than the swash. This therefore erodes the coast.

Formation of Coastal Stack

Collapsed arch

Cave

Wave cut platform

Stack

Example: Old Harry Rocks, Dorset

- Hydraulic action widens cracks in the cliff face over time.
- Abrasion forms a wave cut notch between high tide and low tide.
- Further abrasion widens the wave cut notch to from a cave.
- Caves from both sides of the headland break through to form an arch.
- Weather above/erosion below –arch collapses leaving stack.
- Further weathering and erosion eaves a stump.

Coastal Defences		
Hard Engineering Defences		
Groynes	Wood barriers prevent longshore drift, so the beach can build up.	- Beach still accessible. - No deposition further down coast = erodes faster.
Sea Walls	Concrete walls break up the energy of the wave . Has a lip to stop waves going over.	- Long life span - Protects from flooding - Curved shape encourages erosion of beach deposits.
Gabions or Rip Rap	Cages of rocks/boulders absorb the waves energy, protecting the cliff behind.	- Cheap - Local material can be used to look less strange. - Will need replacing.

Soft Engineering Defences		
Beach Nourishment	Beaches built up with sand, so waves have to travel further before eroding cliffs.	- Cheap - Beach for tourists. - Storms = need replacing. - Offshore dredging damages seabed.
Managed Retreat	Low value areas of the coast are left to flood & erode.	- Reduce flood risk - Creates wildlife habitats. - Compensation for land.

Case Study: Hunstanton and Heacham Coast	
Location and Background Located on the North-West coast of Norfolk. The town is a popular seaside resort. In 2013, the town suffered damage from a storm surge. The Sea Life Centre was flooded and closed for a number of months.	
Geomorphic Processes - The beach widens between Hunstanton and Heacham. - Deposition at Heacham has led to the formation of sand dunes. -Shingle on the beach includes white chalk from Hunstanton Cliffs in the north. -Longshore drift travels from Hunstanton to Heacham.	
Management -The coastline is protected by a number of groynes and a sea wall. -Heacham is also protected by an earth bund. -\$15 million has been spent on beach nourishment to add sediment to beach for increased protection against flooding.	
Middle Course of a River	
Here the gradient get gentler, so the water has less energy and moves more slowly. The river will begin to erode laterally making the river wider.	

Water Cycle Key Terms	
Precipitation	Moisture falling from clouds as rain, snow or hail.
Interception	Vegetation prevents water reaching the ground.
Surface Runoff	Water flowing over the surface of the land into rivers
Infiltration	Water absorbed into the soil from the ground.
Transpiration	Water lost through leaves of plants.
Physical and Human Causes of Flooding.	
Physical: Prolong & heavy rainfall Long periods of rain causes soil to become saturated leading runoff.	Physical: Geology Impermeable rocks causes surface runoff to increase river discharge.
Physical: Relief Steep-sided valleys channels water to flow quickly into rivers causing greater discharge.	Human: Land Use Tarmac and concrete are impermeable. This prevents infiltration & causes surface runoff.
Upper Course of a River	
Near the source, the river flows over steep gradient from the hill/mountains. This gives the river a lot of energy, so it will erode the riverbed vertically to form narrow valleys.	

Formation of a Waterfall	
	1) River flows over alternative types of rocks.
	2) River erodes soft rock faster creating a step.
	3) Further hydraulic action and abrasion form a plunge pool beneath.
	4) Hard rock above is undercut leaving cap rock which collapses providing more material for erosion.
	5) Waterfall retreats leaving steep sided gorge.

Formation of Ox-bow Lakes			
Step 1		Step 2	
	Erosion of outer bank forms river cliff. Deposition inner bank forms slip off slope.		Further hydraulic action and abrasion of outer banks, neck gets smaller.
Step 3		Step 4	
	Erosion breaks through neck, so river takes the fastest route, redirecting flow		Evaporation and deposition cuts off main channel leaving an oxbow lake.

Case Study - Boscastle flood August 16 th 2004	
Boscastle is a small village in Cornwall. It has a permanent population of under 1000. 90% of jobs in the village are linked to tourism.	

Lower Course of a River	
Near the river's mouth, the river widens further and becomes flatter. Material transported is deposited.	
Formation of Floodplains and levees	
When a river floods, fine silt/alluvium is deposited on the valley floor. Closer to the river's banks, the heavier materials build up to form natural levees.	
- Nutrient rich soil makes it ideal for farming. - Flat land for building houses.	
River Management Schemes	
Soft Engineering	Hard Engineering
Afforestation – plant trees to soak up rainwater, reduces flood risk. Demountable Flood Barriers put in place when warning raised. Managed Flooding – naturally let areas flood, protect settlements.	Straightening Channel – increases velocity to remove flood water. Artificial Levees – heightens river so flood water is contained. Deepening or widening river to increase capacity for a flood.

Hydrographs and River Discharge	
River discharge is the volume of water that flows in a river. Hydrographs who discharge at a certain point in a river changes over time in relation to rainfall	
1. Peak discharge is the discharge in a period of time.	
2. Lag time is the delay between peak rainfall and peak discharge.	
3. Rising limb is the increase in river discharge.	
4. Falling limb is the decrease in river discharge to normal level.	

Case Study: The River Tees	
Location and Background Located in the North of England and flows 137km from the Pennines to the North Sea at Red Car.	
Geomorphic Processes Upper – Features include V-Shaped valley, rapids and waterfalls. Highforce Waterfall drops 21m and is made from harder Whinstone and softer limestone rocks. Gradually a gorge has been formed. Middle – Features include meanders and ox-bow lakes. The meander near Yarm encloses the town. Lower – Greater lateral erosion creates features such as floodplains & levees. Mudflats at the river's estuary.	
Causes of flood - 5 hours of heavy rain (3 inches in 1 hour), Impermeable rock, steep valley sides, thin soils limit vegetation. Buildings narrowing river channel. Narrow bridges trapped debris.	damaged. 75 cars and 8 boats washed away. 150 people had to be rescued. Damage cost £15 million.
Effects of flood - 100 homes and 25 businesses	Responses to flood - Scheme cost £4.6 million. Beds of rivers lowered and channels widened. Bridges widened. Car park raised. Trees removed from near river.